







HELSINKI FOOTSTOOL




1. PLEASE SEPARATE AND IDENTIFY ALL PARTS, MAKING SURE THAT YOU HAVE ALL OF THE PARTS LISTED.
2. TO AVOID ANY SCRATCHES DURING ASSEMBLY, PLEASE ASSEMBLE ON A SOFT MAT OR SIMILAR.
3. PLEASE ASSEMBLE STEP BY STEP AND FOLLOW THE INSTRUCTIONS.
4. WASHERS MUST BE USED.
5. WHILE EACH SCREW AND NUT IS PROPERLY FASTENED, DO NOT OVER FASTEN IT.
6. DO NOT COMPLETELY FASTEN EACH SCREW AND NUT UNTIL ALL THE SCREWS ARE PROPERLY FIXED.




- 1 Use Allen key (J) and spanner (K) to fix footstool (A) to legs (B&C) with bolt and nut (E&I) and washers (G). Loosely tighten the bolts until all bolts are in position. Then cover with all caps (L&M).



- 2 Use Allen key (J) to fix legs together as picture with bolt (F) and washer (G). Cover with cap (L).



- 3** Fasten stool cushion (D) on frame with the fabric ties. And your stool is ready to use.



For care and maintenance tips please visit: [synargy.com/product-care](https://www.synargy.com/product-care)