

BY SYNARGY®
SMART
COMFORT

POLO MASSAGE CHAIR



QUICK START GUIDE &
OPERATING INSTRUCTIONS

QUICK START GUIDE

1

Remove any items from pockets and sit into the chair in a comfortable position.


2

Press the power button, and the chair will begin massaging in automatic mode.

3


You can enjoy the automatic mode as it is, or read these operating instructions to learn about more advanced operation.

BASIC CONTROLS



- **Power button** turns the chair on & off.
- **Heat button** turns the seat heating on & off. The LED light below the button indicates if heating is on or off.
- The rubber cover to the left of the buttons can be lifted to access the USB charging port

AUTOMATIC MODE CONTROLS



- **Auto button** toggles between the four automatic modes:


I Focuses on middle & lower back

II Focuses on middle & upper back, neck and shoulders.

III Focuses on buttocks & lower back

Demo mode rotates through all functions


CHAIR POSITION CONTROLS



The buttons above and below the power button adjust the position of the shoulder rollers.


The buttons left and right of the power button adjust the position of the back rollers.

ADVANCED CONTROLS



- **Air button** toggles the airbags between the following modes, or off:
 1. Pulsing, 2. Long Squeeze, 3. Alternating Squeeze
- **Neck & shoulder button** toggles the rotation direction of the neck & shoulder rollers
- **Tap button** adjusts the tapping motions between the following modes, or off:
 1. Pulse slow, 2. Pulse fast, 3. Constant
- **Knead button** toggles additional kneading movements at the middle back position on & off.


CUP HOLDER INSTALLATION



To install the cup holder, simply take the cup holder unit and line up the two holes with the two pegs on the chair's cup holder bracket. Allow the cupholder to slide downward to lock into place.

To remove, perform the reverse action - lift the cup holder upward and then outward to remove.

POLO MASSAGE CHAIR



Health and Safety Warnings: Do not drop or push anything into any slot of the machine. Please stop immediately and consult your doctor if you feel unwell when using this machine. Not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised. Do not use if you are pregnant, unwell, or have a pre-existing medical condition. Do not sit on the back, armrest, or the leg rest as it may result in damage or injury. Do not press or put your hands into the cloth cover of the massage hands.